



# Sani Cid J-Flex

## Acidic washroom cleaner

### **Description**

**Sani Cid J-Flex** is a highly concentrated citric acid-based daily washroom cleaner for hard water areas.

## **Key properties**

- Mildly acidic, based on citric acid
- Fresh fragrance
- Suitable for all acid resistant washroom surfaces including Chrome and Stainless Steel

#### **Benefits**

- Ideal for use in hard water areas and on all acid resistant surfaces
- Effective cleaning and limescale control
- Leaves a pleasant fragrance
- Convenient and controlled dosing through the J-Flex system

## **Use instructions**

The J-Flex dosing system does give controlled dosing both for triggers and for bucket filling.

## Spray Cleaning:

- 1. Rotate selector to BOTTLE and fill the spray bottle
- 2. Spray the solution directly onto surface or onto a damp cloth and wipe. Rinse or replace the cloth regularly. Use a sponge pad to remove stubborn soil.

#### **Bucket Cleaning:**

- 1. Rotate selector to BUCKET and fill bucket
- 2. Apply the solution with a cloth/sponge or mop and remove the soiled solution.
- 3. For heavy soiling allow a 5 minute contact time before agitating with a brush by hand or machine remove soil solution and rinse

Packaging	Dosages		Amount of RTU solution (litres) per pack	Amount of 750 ml trigger bottles	Amount of 5 litre buckets
1.5 litre	Bucket	1:250	375		75
	Trigger	1:50	75	100	
5.0 litre	Bucket	1:250	1250		250
	Trigger	1:50	250	333	

#### Important:

Do not use on acid-sensitive surfaces, e.g. marble, terrazzo, travertine and other calcareous surfaces. Test material compatibility in a small, inconspicuous place before use.





## Sani Cid J-Flex

#### **Technical data**

Appearance: clear, red coloured liquid

Relative density [20°C]: 1.15 pH-value neat: 2.5 - 3.0 pH-value for both solution rates: 3.5 - 4.5

The above data is typical of normal production and should not be taken as a specification.

## Safe handling and storage information

#### Safe handling:

Rinse and dry hands after use. The use of a skin reconditioning cream, such as Soft Care Dermasoft, may be beneficial. For prolonged contact, protection for the skin may be necessary.

Full guidance on the handling and disposal of this product is provided in a separate Material Safety Data Sheet.

Only for professional users / specialists.

### **Storage Information:**

Store in original closed containers away from extremes of temperature.

#### **Environmental information**

The surfactants used in this product are biodegradable in compliance with the requirement of EC Directives 73/404/EEC and 73/405/EEC and their subsequent amendments.

## Available pack sizes

Article code Pack size 7512231 1x1.5L 7512239 1x5L

 $\textbf{JohnsonDiversey} \ (\mathsf{UK})$ 

Weston Favell Centre Northampton NN3 8PD Tel. 0800 525 525

www.johnsondiversey.com